

Addendum Sheet - Inset Tray Models

Fig. 1 - Page 6, should read as follows :-

Check the chimney pot / terminal and general condition of the brickwork or masonry. If the chimney or flue is in poor condition or if there is no up-draught do not proceed with the installation. If there is a history of down-draught conditions with the chimney / flue, a tested and certificated flue terminal or cowl suitable for the relevant flue type should be considered.

6. **A spillage test must always be carried out during commissioning of the appliance.**

**1.6 FIRE PLACE OPENING AND CHIMNEY CATCHMENT SPACE**

This product can be fitted to a cast surround or to builders openings fitted with an existing chairbrick. The opening dimensions should be as shown below in figure 1.

Fig. 1

